Appendix C Sun Documentation

Appendix C lists Software manual sets, a la carte software manuals and hardware manuals. This is a partial list of Sun documentation. To get the most up-to-date list of manuals, contact Sun's Telemarketing Group by calling 1-800-USA-4SUN (prompt 6 for Telemarketing). A Sun representative will help you order the appropriate documentation.

C.1 Software Manual Sets

SunOS 4.0

SX-9A Beginner's Guide set includes the following manuals:

800-1715 Read This First: Beginner's Guides 4.0 SunOS
800-1712 Manual Cover Sheet 4.0 SunOS Beginner's Guides
800-1702 Sun System Overview
800-1703 Getting Started with SunOS: Beginner's Guide
800-1704 Setting Up Your SunOS Environment: Beginner's Guide
800-1705 Self Help with Problems: Beginner's Guide
800-1706 SunView 1: Beginner's Guide
800-1709 Mail and Mail Messages: Beginner's Guide
800-1710 Doing More with UNIX: Beginner's Guide
800-1711 Using the Network: Beginner's Guide

SX-9B System Administration Guide set includes the following manuals:

800-1745 Read This First: System Administration Guides 4.0 SunOS
800-1739 Manual Cover Sheet 4.0 SunOS System Administration Guides
800-1731 SunOS 4.0 Change Notes
800-1732 Installing the SunOS
800-1733 System and Network Administration
800-1735 Security Features Guide
800-1736 PROM User's Guide
800-1738 Sun System Diagnostics Manual

SX-9C System Reference Manual set includes the following manuals:

800-1760 Read This First: System Reference Manuals 4.0 SunOS
800-1759 Manual Cover Sheet 4.0 SunOS System Reference Manuals
800-1751 SunOS Reference Manual
800-1753 System Services Overview
800-1754 Editing Text Files
800-1755 Using nroff AND troff
800-1756 Formatting Documents

SX-9D Programmer's Reference Guide set includes the following manuals:

800-1789 Read This First: Programmer's Tools 4.0 SunOS
800-1776 Manual Cover Sheet 4.0 SunOS Programmer's Tools
800-1771 C Programmer's Guide
800-1773 Assembly Language Reference Manual for Sun-2 and Sun-3

800-1774 Programming Utilities and Libraries
800-1775 Programming Debugging Tools
800-1779 Network Programming
800-1780 Writing Device Drivers
800-1783 SunView Programmer's Guide
800-1784 SunView 1 System Programmer's Guide
800-1785 Pixrect Reference Manual
800-1786 SunCGI Reference Manual
800-1787 SunCore Reference Manual

SS-9A SPARC Reference Manual set includes the following manuals:
800-1743 Read This First: SPARC 4.0 SunOS
800-1744 Manual Cover Sheet 4.0 SunOS SPARC
800-1742 SPARC Release Notes for 4.0
800-1788 Sun-4 Assembly Language Reference Manual
800-1795 A RISC Tutorial
800-1796 Porting Software to SPARC Systems

C.2 Software a la carte Manuals

1. OPERATING SYSTEM MANUALS

SunOS 4.0
800-1702 Sun System Overview 09May88
800-1703 Getting Started with SunOS: Beginner's Guide 09May88
800-1704 Setting Up Your SunOS Environment: Beginner's Guide 09May88
800-1705 Self Help with Problems: Beginner's Guide 09May88
800-1706 SunView 1: Beginner's Guide 09May88
800-1709 Mail and Mail Messages: Beginner's Guide 09May88
800-1710 Doing More with UNIX: Beginner's Guide 09May88
800-1711 Using the Network: Beginner's Guide 09May88
800-1731 SunOS 4.0 Change Notes 09May88
800-1732 Installing the SunOS 09May88
800-1733 System and Network Administration 09May88
800-1735 Security Features Guide 09May88
800-1736 PROM User's Guide 09May88
800-1738 Sun System Diagnostics Manual (version 4.0) 09May88
800-1742 SPARC Release Notes for 4.0 09May88
800-1751 SunOS Reference Manual 09May88
800-1753 System Services Overview 09May88
800-1754 Editing Text Files 09May88
800-1755 Using nroff AND troff 09May88
800-1756 Formatting Documents 09May88
800-1771 C Programmer's Guide 09May88
800-1773 Assembly Language Reference Manual for Sun-2 and Sun-3 09May88
800-1774 Programming Utilities and Libraries 09May88
800-1775 Programming Debugging Tools 09May88

800-1779 Network Programming 09May88
800-1780 Writing Device Drivers 09May88
800-1783 SunView Programmer's Guide 09May88
800-1784 SunView 1 System Programmer's Guide
800-1785 Pixrect Reference Manual 09May88
800-1786 SunCGI Reference Manual 09May88
800-1787 SunCore Reference Manual 09May88
800-1788 Sun-4 Assembly Language Reference Manual 09May88
800-1795 A RISC Tutorial 09May88
800-1796 Porting Software to SPARC Systems 09May88

SunOS 3.x

800-1254 Pixrect Reference Manual 17Feb86
800-1256 SunGCI Reference Manual 17Mar86
800-1257 SunCore Reference Manual 17Feb86
800-1270 Games, Demos and Other Pursuits: Beginner's Guide 17Feb86
800-1284 Getting Started with UNIX: Beginner's Guide 17Feb86
800-1285 Setting Up Your UNIX Environment: Beginner's Guide 01Feb86
800-1286 Self Help with Problems: Beginner's Guide 17Feb86
800-1287 Windows and Windows Based Tools: Beginner's Guide 17Feb86
800-1288 Mail and Mail Messages: Beginner's Guide 17Feb86
800-1289 Doing More with UNIX: Beginner's Guide 17Feb86
800-1290 Using the Network: Beginner's Guide 17Feb86
800-1295 Commands Reference Manual 17Feb86
800-1300 Sun System Overview 17Feb86
800-1301 Programming Utilities for the Sun Workstation 17Feb86
800-1303 UNIX Interface Reference Manual 19Sep86
800-1304 Writing Device Drivers for the Sun Workstation 19Sep86
800-1319 Editing Text File on the Sun Workstation 17Feb86
800-1320 Formating Documents on the Sun Workstation 17Feb86
800-1321 Using nroff AND troff on the Sun Workstation 17Feb86
800-1322 Using UNIX Text Utilities on the Sun Workstation 17Feb86
800-1323 System Administration for the Sun Workstation 17Feb86
800-1324 Networking on the Sun Workstation 17Feb86
800-1325 Debugging Tools for the Sun Workstation 17Feb86
800-1341 UNIX Interface Overview 05Feb86
800-1342 SunView System Programmer's Guide 19Sep86
800-1345 SunView Programmer's Guide 15Oct86
800-1371 FORTRAN Programmer's Guide 17Feb86
800-1372 Assembly Language Reference Manual 17Feb86
800-1376 Pascal Programmer's Guide 17Feb86
800-1379 Programmer's Reference Manual for Curses on the Sun Workstation 15Feb86
800-1521 Installing UNIX on the Sun Workstation 19Sep86
800-1541 System V Enhancements Overview 15Oct86
800-1552 Floating-Point Programmer's Guide for the Sun Workstation 19Sep86
800-1620 Make User's Guide 16Mar87
800-2111 Sun System Diagnostics (sysdiag) Manual 20Nov87

800-1344 Release 3.0 Change Notes 17Feb86

800-1364 Release 3.2 Manual for the Sun Workstation 10Oct86

800-1613 Release 3.3 Manual for the Sun Workstation 15Jan87

800-1614 Release 3.4 Manual for the Sun Workstation 13May87

800-2089 Release 3.5 Manual for the Sun Workstation 20Nov87

800-2181 Reference Manual Insertion Pages for Release 3.5 20Nov87

800-1460 Read This First: Software Notes for Sun UNIX Release 3.2 19Jan87

800-1936 Read This First: Notes for Sun UNIX Release 3.4
(Appendix C of p/n: 800-1614) 18Jun87

800-2129 Read This First: Release 3.4 Installation Update 18Aug87

800-2149 Read This First: Release 3.5 14Jan88

800-2299 Read This First: 2-Disk Subsystems Kernel Configuration
08Jan88 >SunOS Sys4-3.2

800-1399 The SPARC Architecture Manual 22Oct87

800-1562 A RISC Tutorial 30Nov87

800-1593 SunOS 3.2 for the Sun-4 30Nov87

800-1596 Porting Software to SPARC Systems 30Nov87

800-2053 Sun-4 Assembly Language Reference Manual 30Nov87

800-2186 Supplemental Reference Manual Pages for Sys4-3.2 30Nov87

800-2196 Read This First: Sys4-3.2_Rev 2 19Apr88

800-2389 Read This First: SunOS Sys4-3.2 and the 32 MByte Memory Board 01Apr88

SunOS 2.0

800-1150 System Administration Guide for the Sun Workstation 15May85

800-1158 Installing UNIX Manual 05Apr85

800-1165 Programmer's Reference Manual for SunCore 15May85

800-1166 Programmer's Reference Manual for SunCGI 15May85

800-1167 Programmer's Reference Manual for SunWindows 15May85

800-1168 Programmer's Reference Manual for Curses on the Sun Workstation 01Mar85

800-1169 Beginner's Guide to the Sun Workstation 15May85

800-1172 Commands Reference Manual for the Sun Workstation 15May85

800-1173 System Interface Manual for the Sun Workstation 15May85

800-1174 Editing and Text Processing on the Sun Workstation 15May85

800-1175 FORTRAN Programmer's Guide for the Sun Workstation 15May85

800-1176 Pascal Programmer's Guide for the Sun Workstation 15May85

800-1177 Networking on the Sun Workstation 15May85

800-1178 System Summary and Change Notes for the Sun Workstation 15May85

800-1179 Assembler Language Reference Manual for the Sun Workstation 15May85

800-1180 Programming Tools for the Sun Workstation 15May85

800-1181 Systems Internals Manual for the Sun Workstation 15May85

800-1182 Programmer's Tutorial to SunWindows 15May85

800-1195 Device Drivers Manual for the Sun Workstation 15May85

800-1380 Release 2.3 Manual for the Sun Workstation 01Mar86

800-1235 Read This First: Software Notes for UNIX Release 2.3 17Mar86

800-1244 Errata Notes for 2.0 System Administration Manual 15Apr85

MISC SunOS

800-1419 The UNIX System: A Sun Technical Report 1985

2. UNBUNDLED SOFTWARE MANUALS

SunINGRES

800-1394 SunINGRES Application Notes 17Feb86

800-1681 SunINGRES Installation Guide 16Jan87 [replaced by 800-3106]

800-1906 SunINGRES 5.0 Release Notes 01Dec86

800-1907 SunINGRES Project Management Demo Guide 19Jan86

800-3106 SunINGRES Installation Guide 01Aug88

800-1999 Read This First: SunINGRES 5.0 15Oct87 [replaced by 800-2473]

800-2473 Read This First: SunINGRES 5.1 27May88 [replaced by 800-3105]

800-3105 Read This First: SunINGRES 5.1 01Aug88

SunAlis

800-1669 SunAlis Administration Guide 01Feb87

800-1670 SunAlis Introductory User's Guide 01Feb87

800-1671 SunAlis Document Composer's Guide 01Feb87

800-1672 SunAlis Graphics Guide 01Feb87

800-1673 SunAlis Spreadsheet Guide 01Feb87

800-1674 SunAlis Database Guide 01Feb87

800-2066 Read This First: SunAlis Release 2.1 30Jul87

SunTrac

800-2058 SunTrac User's Guide 16Sep87

800-2059 SunTrac Reference Guide 16Sep87

800-2060 SunTrac Tutorial 16Sep87

800-2061 SunTrac Installation Guide 16Sep87

800-2082 Read This First: SunTrac 1.0 30Oct87

800-2161 Read This First: SunTrac 1.0 30Oct87

800-2204 Read This First: SunTrac 1.0 New Features and Potential Problems in Installation (for Sun-4 under SunOS Sys4-3.2) 10Dec87

800-2205 Read This First: SunTrac 1.0 More New Features and Potential Problems in Installation (for Sun-4 under SunOS Sys4-3.2) 10Dec87

SunUNIFY

800-1566 SunUNIFY Overview 19Dec86

800-1567 SunUNIFY Programmer's Manual 19Dec86

800-1568 SunUNIFY Tutorial 19Dec86

800-1569 SunUNIFY Reference Manual 19Dec86

800-1576 SunUNIFY Installation Guide 19Dec86

800-1583 Change Notes For SunUNIFY Release 2.0 19Dec86

800-1578 Read This First: Notes for SunUNIFY Release 2.0 24Jul87

SunSimplify

800-1542 SunSimplify Overview 19Dec86

800-1543 SunSimplify Tutorial 19Dec86

800-1544 SunSimplify Reference Manual for databrowse and schemadesign 19Dec86

800-1570 SunSimplify Programmer's Manual for ERIC 19Dec86

800-1584 SunSimplify Installation Guide 19Dec86

800-1488 Read This First: Notes for Sun Simplify Release 1.0 24Jul87

NeWS "Network-extensible Window System"

800-2144 NeWS 1.1 Release Notes 15Jan88

800-2145 News 1.1 Installation Guide 15Jan88

800-2146 NeWS 1.1 Manual 15Jan88

800-2147 NeWS Application Scenario 15Jan88

800-2162 NeWS Technical Overview 15Jan88

800-2152 Read This First: NeWS 1.1 25Feb88

800-2249 Portable NeWS 1.1 Installation Guide 19Feb88

800-2250 Portable NeWS 1.1 Porting Manual 05Feb88

800-2251 Read This First: Portable NeWS 1.1 11Mar88

800-2280 Sample NeWS 1.1 Manual 15Jan88

SunGKS "Graphical Kernel System"

800-2170 SunGKS Reference Manual 13Nov87

800-2171 SunGKS Software Installation Manual 13Nov87

800-2172 Read This First: SunGKS 2.1 17Nov87

SunPHIGS "Programmers Hierarchical Interactive Graphics System"

800-3061 Getting Started with SunPHIGS 30Jun88

800-2464 SunPHIGS Software Installation 30Jun88

800-2475 SunPHIGS Reference Manual 30Jun88

NSE "Network Software Environment"

800-2095 Network Software Environment Reference Manual 11Mar88

800-2096 Network Software Environment Installation and Administration 11Mar88

800-2202 Read This First: Network Software Environment (version 1.0) 18Mar88
[replaced by 800-3076]

800-2461 Read This First: Network Software Environment (version 1.05) 20May88

800-3076 Read This First: Network Software Environment (version 1.1) 01Aug88

Sun Common Lisp

- Development Environment (for Sun-2 and Sun-3)

800-1517 Sun Common Lisp User's Guide 02Feb86

800-1518 Sun Common Lisp Reference Guide 02Feb86

800-1519 Sun Common Lisp Installation Guide 02Feb87

800-2069 Sun 2.1 Common Lisp Release Notes 01Sep87

800-2151 Sun 2.1 Common Lisp Object System 25Sep87

800-2084 Read This First: Sun Common Lisp 2.1 Development Environment 02Oct87

- Application Environment (for Sun-2 and Sun-3)

800-1941 Sun Common Lisp Applications Environment 01Apr87

800-1946 Read This First: Sun Common Lisp 1.1 Application Environment 16Oct87

- Development Environment (for Sun-4)

800-1519 Sun Common Lisp Installation Guide [find the price in the "Development Environment" section above]

800-2069 Sun 2.1 Common Lisp Release Notes [find the price in the "Development Environment" section above]

800-2372 Sun Common Lisp 2.1 User's Guide (runs on Sun-4 under SunOS Sys4-3.2) 01Feb88

800-2373 Sun Common Lisp 2.1 Reference Manual 01Feb88

800-2374 Read This First: Sun Common Lisp for the Sun-4 18Mar88

Sun FORTRAN (under SunOS 3.x)

800-1371 FORTRAN Programmer's Guide [find the price in the "SunOS 3.x" section above]

800-1976 Sun FORTRAN with VMS Extensions - Release Notes 04Sep87

800-1977 Sun FORTRAN with VMS Extensions - Installation Guide 04Sep87

800-2067 Read This First: Sun FORTRAN 1.0 - with VMS Extensions 18Sep87

Sun FORTRAN (for Sun-4 under SunOS Sys4-3.2)

800-2185 Sun FORTRAN 1.05 Release Notes 30Nov87

800-2200 Read This First: FORTRAN 1.05 Upgrade 30Nov87

Sun FORTRAN (under SunOS 4.0)

800-2163 Sun FORTRAN Programmer's Guide 06May88

800-2469 Read This First: Fortran 1.1 06May88

Sun Pascal

800-2191 Sun Pascal 1.05 Release Notes 12Feb87

800-2209 Read This First: Sun Pascal 1.05 Running on Sun-4 under SunOS Sys4-3.2 12Feb87

Sun Cross Compilers

800-2103 Sun Cross-Compilers User's Guide 23Oct87

800-2178 Sun Cross-Compiler Domesticating Kit Installation Guide 23Oct87

800-2086 Read This First: Sun Cross-Compilers 2.0 13Nov87

Sun Modula-2

800-1514 Using Modula-2 on the Sun Workstation 20Oct86

800-2108 Sun Modula-2 Release 2.0 Notes 04Jan88

800-2143 Sun Modula-2 Installation Guide 04Jan88

800-2109 Read This First: Sun Modula-2 (Release 2.0) 05Feb88

SunLink

- SunLink SNA 3270

800-1918 SunLink 3270 User's Guide 31Jul87

800-1919 SunLink SNA 3270 System Administration Guide 07Aug87

800-1920 SunLink 3270 Programmer's Guide 31Jul87

800-1991 Read This First: SunLink SNA 3270 (version 5.0) 21Aug87

800-2260 Read This First: SunLink SNA 3270 (version 5.1 - runs on Sun-4 under SunOS Sys4-3.2) 05Feb88

- SunLink BSC 3270

800-1504 SunLink BSC 3270 System Administration Guide 02Sep86

800-1586 SunLink 3270 User's Guide 29Aug86

800-1587 SunLink 3270 Programmer's Guide 29Aug86

800-1505 Read This First: SunLink BSC 3270 (version 3.0) 02Sep86

- SunLink Local 3270

800-1917 SunLink Local 3270 Systems Administration Guide 31Jul87

800-1918 SunLink 3270 User's Guide [find the price in the "SNA 3270" section above]

800-1920 SunLink 3270 Programmer's Guide [find the price in the "SNA 3270" section above]

800-2042 Read This First: SunLink Local 3270 (version 5.0) 02Oct87

- SunLink SNA Peer-To-Peer

800-1933 SunLink SNA Peer-To-Peer System Administration Guide 14Aug87

800-1934 SunLink SNA Peer-To-Peer API Programmer's Guide 14Aug87

800-1935 SunLink SNA Peer-To-Peer DIA Programmer's Guide 14Aug87

800-1990 Read This First: SunLink SNA Peer-To-Peer (version 5.0) 06Nov87

- SunLink BSC RJE

800-2101 SunLink BSC RJE System Administration Guide 04Dec87

800-2102 SunLink BSC RJE User's Guide 08Dec87

800-2100 Read This First: SunLink BSC RJE (version 5.0) 04Dec87

800-1389 SunLink BSC RJE System Administrator's Guide (version 3.0) 01Jun86

800-1390 SunLink BSC RJE User's Guide (version 3.0) 01Jun86

800-1508 Read This First: SunLink BSC RJE (version 3.0) 06Jun86

- SunLink OSI

800-1928 SunLink OSI System Administration Guide 31Jul87

800-1929 SunLink OSI Programmer's Guide 31Jul87

800-1988 Read This First: SunLink OSI (version 5.0) 31Jul87

- SunLink X.25

800-1924 SunLink X.25 System Administration Guide 31Jul87

800-1925 SunLink X.25 System User's Guide 31Jul87

800-1926 SunLink X.25 Programmer's Guide 31July87

800-1992 Read This First: SunLink X.25 - revised (version 5.0) 12Feb88

800-2259 Read This First: 5.1 SunLink X.25 (runs on Sun-4 under SunOS Sys4-3.2) 12Feb88

800-1333 SunLink X.25 Programmer's Guide (version 2.0) 18Feb86

800-1348 SunLink X.25 System Administrator's Guide (version 2.0 and 3.0) 18Feb86

800-1359 Read This First: SunLink X.25 (version 2.0) 06Jun86

- SunLink DDN

800-1927 SunLink DDN System Administration Guide 07Aug87

800-2045 Read This First: SunLink DDN (version 5.0) 21Aug87

- SunLink Internetwork Router

800-1923 SunLink Internetwork Router System Administration Guide 31Jul87

800-2044 Read This First: SunLink Internetwork Router (version 5.0) 14Aug87

- SunLink DNI

800-1930 SunLink DNI Programmer's Guide 21Jul87

800-1931 SunLink DNI User's Guide 21Jul87

800-1932 SunLink DNI System Administration Guide 21Aug87

800-2046 Read This First: SunLink DNI (version 5.0) 09Oct87

800-2307 Read This First: 5.1 SunLink DNI (runs on Sun-4 under SunOS Sys4-3.2) 15Apr88

- SunLink TE100

800-1513 SunLink TE100 User's Guide 21Aug87

800-1539 Read This First: SunLink VT100-type Terminal Emulator (version 4.0) 09Oct87

800-2218 Read This First: SunLink TE100 (version 5.1 - runs on Sun-4 under SunOS Sys4-3.2) 23Jan88

SunLink Communication Hardware Products

- SunLink Channel Adapter

800-1921 SunLink Channel Adapter Software Installation and Configuration Guide 31Jul87

800-2092 SunLink Channel Adapter Programmer's Guide 31Jul87

800-2043 Read This First: SunLink Channel Adapter (version 5.0) 02Oct87

- Installation Notes and Configuration Procedures

813-1034 SunLink Channel Adapter Installation Notes 28Sep87

813-2040 SunLink Channel Adapter Configuration Procedures 28Sep87

813-2041 Cardcage Slot Assignments and Backplane Configuration Procedures for the SunLink Channel Adapter 21Oct87 [replaced by 813-2004]

- SunLink Multiprotocol Communication Processor

800-1922 SunLink Multiprotocol Communication Processor Software Installation and Configuration Guide 07Aug87

800-2423 Read This First: 5.2 SunLink MCP 08Apr88

800-2035 Read This First: SunLink MCP (version 5.0) 21Aug87

- Installation Notes and Configuration Procedures

813-1033 4 Channel SunLink Multiprotocol Communication Processor Field Service Manual and Installation Notes 18Aug87

813-2032 SunLink Multiprotocol Communications Processor Configuration Procedures 20Aug87

813-2043 Cardcage Slot Assignments and Backplane Configuration Procedures for the SunLink Multiprotocol Communications Processor 20Aug87 [replaced by 813-2004]

- Other SUNLINK

800-1398 SunLink Communications Processor Installation and Configuration Guide 01Jun86

800-1509 Read This First: SunLink Communication Processor (version 3.0) 01Oct86

C.3 Hardware a la carte Manuals

1. Sun Systems

Sun-2/100U/150U

800-0485 Power Drain Specifications (Sun PCBs) 08May82

Sun-2/120/170

800-0485 Power Drain Specifications - Sun PCBs [find the price in the "Sun-2/100U/150U" section above]

800-1170 Hardware Installation Manual for the Sun-2/120 15May85

800-1171 Hardware Installation Manual for the Sun-2/170 15May85

800-1228 Sun-2/120 and Sun-2/170 Rev. R PROM Release Notes 14Mar85

813-2014 Sky Board Configuration Procedures for the Sun-2/120/170 Workstations 02Jul86

Sun-2/50/130/160

800-1143 Hardware Installation Manual for the Sun-2/50 Desktop SunStation 19Nov84

800-1144 Hardware Installation Manual for the Sun-2/160 Desktop SunStation 15Apr85

800-1149 Read Me First: Unpacking the Sun-2/50 03Jan85

800-1160 Read Me First: Unpacking the Sun-2/160 12Jun85

800-1188 Installing the Mouse/Keyboard Connector (Sun-2/50 Mouse/Keyboard) 03Jan85

800-1196 Installing Revision Q EPROMS on the Sun-2/160 CPU Board 15Apr85

800-1400 Installation Note for Sun-2/160: Configuration Requirements for Use of Graphics Processor Board and Graphics Buffer Board 18Jul85

800-1402 Installation Instructions for the Sun-2/50 SCSI or Floating Point Processor 01Jul85

813-2015 Sky Board Configuration Procedures for the Sun-2/130/160 Workstations 02Jul86

Sun-2 Miscellaneous

800-1193 User's Manual for the Sun-2 VME - Multibus Adapter Board 25Sep86

Sun-3/50

800-1355 Sun-3/50 Desktop Workstation Hardware Installation Manual 31Jan86

800-2197 Errata: Sun-3/50 Desktop Workstation Hardware Installation Manual 01Dec87

Sun-3/60

800-1905 Sun-3/160 Special Release: Software Installation Guide and Change Notes 03Aug87

800-2128 Read This First: Sun-3/60 Software Release 14Sep87

813-1030 SIMM Installation Guide for the Sun-3/60 Workstation 08Jan88

813-1031 Color Frame Buffer Board Installation Guide for the Sun-3/60 Workstation 08Jan88

Sun-3/75

800-1312 Hardware Installation Manual for the Sun-3/75 Desktop SunStation 31Sep86

Sun-3/110

800-1616 Installation Manual for the Sun 3-Slot Logic Enclosure 10Dec86

800-1953 Sun 3-Slot Foot Support Installation Manual 13Apr87

Sun-3/150

800-1902 Installation Manual for the Sun 6-Slot Deskside Logic Enclosure 01Oct87

800-2179 Read Me First: 6-Slot PROM Information 01Oct87

Sun-3/160/180

800-1314 Hardware Installation Manual for the Sun-3/160 SunStation 03Mar86

800-1534 Read Me First: the Sun-3/180 ALM Patch Tape 24Apr86

800-1945 Installation Manual for the Sun 12-Slot Deskside Logic Enclosure 03Jun87

813-1004 Installation and Service Manual for the Sun-3/180 16 Channel Asynchronous Line Multiplexer 04Jun86

813-2008 Sun-3/180 16 Channel Asynchronous Multiplexer Configuration Procedures 20May86

Sun-3/260/280

800-1528 Hardware Installation Manual for the Sun-3/260 Workstation 10Oct86

Sun-3 Miscellaneous

800-1487 User's Guide to the Sun-3/100 VMEbus 24Nov87

800-1910 Read Me First: Sun-3/200s + CDC 1/2" Drive + Tape Master Controller 15Jan87

813-2047 Sun 3004 CPU Board Configuration Procedures 27Oct87

Sun-4/110

800-2124 Installation Notes for the Sun 4100 Board Set 15Jan88

800-2300 Read Me First: Floating Point Unit Option for the Sun-4/100 Series 02Mar88

800-2375 Read Me First: Sun-4/110 Systems 02Mar88

813-1040 Sun P4 Color Frame Buffer Board Installation Manual 21Feb88

813-1041 Sun P4 Monochrome Frame Buffer Board Installation Manual 21Feb88

813-2053 Cardcage Slot Assignments and Backplane Configuration Procedures for the Sun-4/110 21Feb88 [replaced by 813-2004]

2. Backplane

813-2004 Cardcage Slot Assignments and Backplane Configuration Procedures for the Sun-2/3/4 08Jun88

813-2025 Cardcage Slot Assignments and Backplane Configuration Procedures for the Sun-3/140 Workstation 10Dec86

813-2037 Sun-4/200 Cardcage Slot Assignments and Backplane Configuration Procedures 01May87 [replaced by 813-2004]

813-2038 Cardcage Slot Assignments and Backplane Configuration Procedures for the Sun-3/150 01Oct87 [replaced by 813-2004]

3. Peripherals

Sun-3 Shoebox

813-1010 Sun-3 Mass Storage Subsystem Installation Manual 71 and 141 MByte Drives 25Aug86

813-1020 Sun-3 Mass Storage Subsystem Installation Manual 71, 141 and 327 MByte Drives 29Jul87

800-2329 Errata: Sun-3 Mass Storage Subsystem Installation Manuals (part numbers: 813-1010-06 and 813-1020-07)

Small Computer Systems Interface (SCSI)

800-2117 Read Me First: Formatting and Labeling 327 MByte Disk Drives 21Jan88

800-2190 Read This First: SCSI Software Patch (for SCSI - 3 VME Running SunOS Release 3.2, 3.4)

813-1015 Installation and Service Manual for the Sun-3 Small Interface Circuit Card 20May86

813-2007 Sun-3 SCSI Configuration Procedures 08May86

SMD Disk

800-2176 Read Me First: Sun 900 MByte Disk Drive 29Dec87

813-1009 Sun Mass Storage Pedestal Installation Manual 17Sep86

813-1013 Sun 575 MByte Disk Drive Installation Manual 21Jul86

813-1027 VMI/SMD Disk Controller Installation Note 02Aug88

813-2002 Xylogics 450/451 SMD Controller Board Configuration Procedures 01Apr87

813-2005 Fujitsu 2361A Disk Drive Configuration Procedures 03Sep86

813-2006 280 MByte Disk Drive Configuration Procedures 02Apr87

813-2033 VME/SMD Disk Controller Configuration Procedures 12Nov87

813-2046 Sun 900 MByte Disk Drive Configuration Procedures 29Dec87

1/4-Inch Tape

800-1315 A Tutorial on 1/4 Inch Tape Drives 15Jul86

813-1016 Installation and Service Manual for the Sun-3/180 Tape Drive Option 31May86

813-2011 Sun-3 Emulex MT02 Controller Configuration Procedures 03Mar87

1/2-Inch Tape

813-1002 Fujitsu GCR Tape Drive Hardware Installation Manual 02May86

813-1016 Installation and Service Manual for the Sun-3/180 Tape Drive Option [find the price in the "1/4 Inch Tape" section above]

813-2001 Xylogics 472 Tape Controller Board Configuration Procedures 02May86

LaserWriter

800-1249 Installing the LaserWriter 01May86

800-1305 Read This First: Notes for Transcript Release 2.0 11Jul86

3. Enclosures

Racks

800-1255 Hardware Installation Manual for the Sun-2/170 Rackmounted System 01Jun85

800-1555 Installation Manual for the Sun Full-height Rack System 16Jul86

800-1676 Installation Manual for the Sun Rackmountable Fileservers 01Jan87 [replaced by 800-1677]

800-1677 Installation Manual for the Sun Full-height Rack System 26Jan87

813-1014 Installation Manual for the Half-height rack 19May86

Pedestals

800-1616 Installation Manual for the Sun-3 Slot Logic Enclosure [find the price in the "Sun-3/110" section above]

800-1902 Installation Manual for the Sun 6-Slot Deskside Logic Enclosure [find the price in the "Sun-3/150" section above]

800-1945 Installation Manual for the Sun 12-Slot Deskside Logic Enclosure [find the price in the "Sun-3/160/180" section above]

800-1953 Sun 3-Slot Foot Support Installation Manual [find the price in the "Sun-3/110" section above]

4. Boards

CPU

800-1615 Installation Notes for the 501-1164 CPU Board 10Dec86

800-1618 Installation Notes for the Sun 3200 Board Set 09Jan87

800-1619 Installation Notes for the 501-1134 CPU Board 10Dec86

800-1684 Installation Notes for the Sun 4200 Board Set 21Dec87

813-2013 Sun 501-1134 CPU Board Configuration Procedures 01Sep86

813-2017 Sun 501-1206 CPU Board Configuration Procedure 10Oct86

813-2031 Sun 4200 CPU Board Configuration Procedures 21Dec87

813-2049 Sun 4100 Board Set Configuration Procedures 15Jan88

Memory

800-2123 Installation Notes for the 32 MByte Memory Board 11Mar88

813-2018 Sun 501-1102 Memory Board Configuration Procedure 10Oct86

FPA/FPP/FPU

800-1378 Sun Floating Point Accelerator User's Manual (for Sun-3 Systems) 02Jun86

813-1012 Installation Notes for the Sun FPA Board 06Jun86

813-2012 Sun Floating Point Accelerator Board Configuration Procedure 11Nov87

Video/Graphics

800-1571 Sun Graphics Processor Software Interface Manual (version 3.2 and below) 01Dec86

800-1986 Graphics Processor Software Interface (GPSI) Programmer's Guide 04Mar87

800-2328 Read This First: GP2 Release 1.0 FCS 26Mar88

800-2330 Installation Notes for the GP2 and CG5 Boards 23Feb88

813-2023 Graphic Processor+ Board Configuration Procedure 26Aug86

Communications

800-2210 Read Me First: Asynchronous Line Multiplexer-2 01Dec87

800-2235 Read This First: ALM-2 Board System Configuration 07Dec87

813-1001 Installation and Service Manual for the VME Asynchronous Line Multiplexer 08May86

813-1007 Installation and Service Manual for the Multiple Terminal Interface Board 12Jul85

813-1029 16 Channel Asynchronous Line Multiplexer-2 Field Service Manual and Installation Notes 07Dec87

813-2003 VME Asynchronous Line Multiplexer Configuration Procedures 20May86

813-2042 16 Channel Asynchronous Line Multiplexer-2 Configuration Procedures 01Dec87

813-2045 Cardcage Slot Assignments and Backplane Configuration Procedures for the 16 Channel ALM-2 10Dec87 [replaced by 813-2004]

Miscellaneous Hardware

800-1231 Degaussing the Monitor 1985

800-1406 Installation Note of Installing a Piercing Tap (a.k.a. "vampire") 16Aug85

800-1968 Read Me First: Removing Head-lock Constraints from the 575 MByte Disk Drive 05Mar87

800-2156 Read Me First: Optical Mouse 02Sep87

800-2206 ESD Kit Instructions 06Jan88

813-1021 Installation Notes for Sun MAP-kit Board 12Dec86

813-2029 Sun MAP-kit Board Configuration Procedures 12Dec86